

# UNDERSTANDING POLYCOM® VVX® 601 BUTTONS AND HARDWARE



- 1 USB Ports** - Enable you to:
  - Attach a USB flash drive so you can record calls, update the background picture on your phone, set up a screen saver, or use your phone as a digital picture frame.
  - Attach a USB headset.

---

- 2 Message Waiting Indicator** - Flashes red to indicate new messages.

---

- 3 Home key** - Enables you to press from any screen to display Home view. From Home view, press to display other phone views.

---

- 4 Screen** - The 3.5-inch diagonal screen is backlit.

---

- 5 Speaker** - Provides ringer and hands-free (speakerphone) audio output.

---

- 6 Headset key** - Enables you to place and receive calls through a headset. The key glows green when an analog headset is activated.

---

- 7 Speakerphone key** - Enables you to place and receive calls using the speakerphone. The key glows green when activated.

---

- 8 Mute key** - Mutes your audio during calls and conferences. The key glows red when audio is muted.

---

- 9 Dialpad** - Enables you to enter numbers, letters, and special characters. You can also use the dialpad keys to select menu items that have index numbers.

---

- 10 Volume keys** - Adjusts the volume of the handset, headset, speaker, and phone's ringer.

---

- 11 Security slot** - The connector on the back of your phone that enables you to attach a laptop cable lock to your phone so that you can secure it to a desktop. For more information on locking your phone to the desktop, see Security Slots on Polycom Phones (Technical Bulletin 64654).

---

- 12 Microphone** - Transmits sound from your phone to other phones.

# UNDERSTANDING POLYCOM® VVX® 601

## BUTTONS AND HARDWARE

Icon	Description
	Registered line
	Unregistered line
	Placing a call
	Active call using Polycom HD Voice
	Held call
	Incoming call
	Incoming call
	Active conference
	USB flash drive attached
	Recording in progress or paused (VVX 500 only)
	Recording paused (VVX 600 only)
	Recording in progress (VVX 600 only)
	Placed call
	Received call
	Missed call
	Bluetooth available (VVX 601 only)

Icon	Description
	Status indicators in Lines view. A flashing red bar indicates held calls. A green bar indicates an active call.
	Do Not Disturb enabled
	Phone warning
	Login credentials invalid
	Shared line
	Shared line with a held call
	Call forwarding is enabled
	Tap to access recent calls
	Tap to access messages
	Presence status (Available)
	Presence status (Busy)
	Presence status (Away)
	Presence status (Do Not Disturb)
	Presence status (Offline)
	Presence status (No information)
	Bluetooth headset paired and connected (VVX 600 only)